

PATRIoT Gateway Manual



Specifications

Physical Specifications	
Dimensions	5.6" (142mm) Tall x 1.6" (41mm) Wide x 5.2" (132mm) Deep
Weight	2 lbs (0.9kg)
Housing Material	Powder Coated Steel
Mechanical installation	DIN Rail Mount
Electrical Specifications	
Input Power	6 to 42 Vdc
Power Consumption @ 12Vdc	No Ethernet: 65mA Average, 75mA Max With Ethernet: 85mA Average, 95mA Max
Power Consumption @ 24Vdc	No Ethernet: 35mA Average, 43mA Max With Ethernet: 45mA Average, 53mA Max
Wire Termination	Screw Terminals, 18AWG–22AWG
Clock	Clock and RSD Control Registers Maintained For 30 Days Without Power
Environmental	
Ambient Operating Temperature	-40 to +185°F (-40°C to 85°C)
Humidity	0% – 95% Non-Condensing
Wired Communication Interfaces	
2x RS485/RS232	2 Serial Ports. Individually software Configurable For RS485 or RS232. Server Mode and Client Mode
1x RJ45	10/100 Ethernet Port with TCP/IP, Modbus TCP, EtherNet/IP
1x USB-C	USB-C High Speed Interface for Local Configuration With SignalFire Toolkit
Wired Communication Protocols	
Modbus RTU	30,000 Tags 2000 Remappable Tags Mode: Server Mode: Client
Modbus TCP	30,000 Tags 2000 Remappable Tags 8 Concurrent Clients Mode: Server
EtherNet/IP Adapter	CIP I/O Connections: 2 CIP Input Data Assemblies: 2 x 496 bytes CIP Output Data Assemblies: 2 x 496 bytes
MQTT/Sparkplug	1000 Tags 200,000 Store/Forward Tag Buffer Configurable MQTT Brokers (3) TLS Encryption 1.2
Wireless Communication Interface	
SignalFire 900MHz Star/Mesh Network	Radio Power: 500mW Antenna: External, Omnidirectional Frequency Band: 902MHz – 928MHz ISM License Free, Compliant with FCC Part 15 And Industry Canada Up To 3 Mile Range (Depends on SignalFire Node Type & Condition)
Antenna	
Antenna	RP-SMA Antenna connector

Wireless Communication Protocol	
SignalFire	Mode: Start/Mesh Self Organizing and Self Healing Nodes: 240 (Depends On Update Rate Interval Of Each Node) Remote Configuration Of Nodes Using Over-The-Air Technology
Security	128 Bit AES Encryption, Pre-shared Key Frequency Hopping Replay Prevention
Local Automation	
Remote Shutdown Logic	Configurable With Up To 128 rules
Networking	
Modbus TCP Connections	8 Modbus Concurrent Clients
Web Admin Interface	Configurable Login Credentials and Enable/Disable Control Setting
MQTT/Sparkplug	Configurable Broker (3) with TLS 1.2 Security
IP	Static or DHCP
Network Time	NTP Sync
I/O Expansion Modules	
SignalFire Analog/Relay Output Module	Up to 2 Modules. Each Module Has 8 Analog Outputs and 2 Relay Outputs
SignalFire Digital Output Relay Module	Up to 2 Modules. Each Module Has 12 Digital Outputs
Approvals	
Hazardous Locations	Class 1 Division 2 Certified, Groups C&D, Temperature Code T4 Certified to CSA C22.2 No. 213, Conforms to UL 121201 and 61010
ISM Band	Compliant with FCC Part 15, IC (Industry Canada) Contains FCC ID: W8V-SFTS500, IC: 8373A-SFTS500

Table of Contents


Specifications.....	2
Product Description	7
Connections and Components	9
Operation	11
C1D2 Hazardous Location Installation.....	11
Dimensions.....	12
How To Order.....	13
1. Setup.....	14
1.1 Using the SignalFire Toolkit.....	15
1.2 Web Browser Configuration.....	16
1.3 Web and ToolKit Dashboard Overview.....	17
1.4 PATRIoT Gateway and Firmware updates.....	17
2. Radio Nodes Overview	18
2.1 Table Columns Explained	18
3. Radio Settings.....	22
3.1 Radio Status	22
3.2 Device Settings.....	22
3.3 Save Changes.....	23
4. Info Tab	24
4.1 Device Status.....	24
4.2 Device Actions	24
4.3 Device Settings.....	24
4.4 Clock Setting	24
4.5 Reset to Factory Defaults	24
5. Network Settings.....	25
5.1 Network Status.....	25
5.2 Network Time Protocol (NTP) Status.....	25
5.3 Web Status.....	25
5.4 Editable Network Settings	26
6. Serial Port Settings.....	27
6.1 Port 1 and Port 2 Configuration	27
6.2 Reset and Save Options.....	27

6.3 Modbus RTU Server Mode	28
6.4 Modbus RTU Client Mode	28
6.5 Output Module Mode	29
7. MQTT Configuration	30
7.1 MQTT Status (Left Panel).....	30
7.2 MQTT Client Enable Settings (Right Panel)	30
7.3 Reset and Save Options.....	30
8. Sparkplug Configuration	31
8.1 Sparkplug Status.....	32
8.2 Sparkplug Settings.....	32
8.3 Save Changes.....	32
8.4 Reported Metrics.....	33
8.5 Configuring Sparkplug Using SignalFire Toolkit	33
9. I/O Configuration	38
9.1 I/O Status.....	38
9.2 I/O Settings.....	38
9.3 I/O Wiring.....	39
10. Modbus TCP Configuration	40
10.1 Modbus TCP Status.....	40
10.2 Modbus TCP Settings.....	40
10.3 Reset and Save Options	40
11. EtherNet/IP Configuration.....	42
11.1 Enabling EtherNet/IP	42
11.2 CIP Object Model Overview.....	42
11.3 Adapter Connection Capabilities	43
11.2 EtherNet/IP Assembly Definitions	43
11.3 Network and Port Requirements	44
11.4 Rockwell Automation Configuration (Studio 5000 Using EDS File).....	44
11.5 Data Assembly Mapping.....	46
12. Logs.....	48
12.1 Log Categories.....	48
12.2 Individual Log Access	48
12.3 Accessing Logs from the ToolKit	49
13. User Settings.....	50

13.1 Change Password	50
14. Remote Shutdown (RSD)	51
14.1 RSD Configuration.....	52
14.2 Relay Control Logic.....	53
14.3 Destination Relay.....	54
14.4 RSD Table Example.....	55
14.5 RSD Event log.....	55
14.6 Additional RSD Options	56
15. Local Input/Output.....	57
15.1 Digital Inputs	57
15.2 Digital Outputs	57
16. Modbus Register Remapping	58
16.1 Use Data Type Floats.....	59
16.2 Fail Mode	59
16.3 Import/Export CSV Files	60
17. Modbus Register Map.....	61
17.1 PATRIoT Gateway Registers.....	61
17.2 Output Module Registers	63
18. Disposal Instructions.....	65
19. FCC and IC Statements	67
Technical Support And Contact Information.....	69

Product Description

The PATRIoT Gateway is a versatile hub that connects wireless and wired devices into SCADA, cloud, and monitoring systems with ease. Supporting Modbus TCP, EtherNet/IP, and MQTT/Sparkplug, it seamlessly integrates data from SignalFire's 900 MHz wireless nodes, Modbus devices, and field I/O modules for a flexible, cost-effective solution. With ultra-low power consumption, large-scale tag support, and secure cloud-ready connectivity, the PATRIoT delivers reliable performance in even the most remote applications. Whether you need to shorten cable runs, enable local automation, or scale to thousands of devices, the PATRIoT Gateway provides a powerful platform to modernize and simplify industrial monitoring.



FEATURES

- Integrates wireless + wired signals into SCADA, cloud, or remote systems
- Publishes to MQTT/Sparkplug with no licensing required
- Supports SignalFire Cloud for turnkey monitoring and control
- Ultra-low power consumption (<50mA) for solar-friendly installations
- Large-scale deployment capabilities with up to 30,000 Modbus tags
- Remote shutdown logic with 128 configurable rules for automation
- Optional expansion modules for analog, relay and digital outputs
- Modbus-RTU Client mode for polling wired Modbus devices and IO Modules

Connections and Components

PATRIoT Gateway Connections

The PATRIoT Gateway has 4 pluggable terminal blocks. They provide power, serial communication and I/O. The connections are as follows:

Terminal Name	Connection
6-42VDC +	Positive Power (6 to 42 VDC)
6-42VDC -	Power Ground




The PATRIoT Gateway has local I/O connections on the 6-position pluggable terminal block. The connections are as follows, left to right:

Terminal Name	Connection
GND	Digital Input Ground
DI2	Digital Input 2
DI1	Digital Input 1
GND	Digital Output Ground
DO2	Digital Output 2
DO1	Digital Output 2

Two Serial ports are available on 4-position pluggable terminal block for each port. The connections are as follows, left to right:

Terminal Name	Connection
GND	Ground
B -	RS485 B Terminal
A + / TX	RS485 A Terminal / RS232 TX
RX	RS232 RX



A USB-C port is available for local connection to the SignalFire Toolkit for configuration and diagnostics.

An ethernet port is available for access from a remote terminal for Toolkit configuration and Modbus-TCP commands.

The PATRIoT Gateway has an RP-SMA connection for use with an external 900MHz antenna, purchased from SignalFire or separately. Contact your local SignalFire sales rep for antenna options.

Status LED

The PATRIoT Gateway has a Status LED that blinks as follows:

STATUS LED	Description
Slow Flash (3 second pause)	System is running and has one or more nodes on network
Fast Flash (0.5 second pause)	System is running but no nodes found on network
Solid On	System Fault needs service or rescue bootloader

Smart Button

The button on the front of the PATRIoT Gateway supports the following functions.

Reboot – While running, press and hold the button for 10 seconds to reboot the Gateway

Force Bootloader – With power removed from the Gateway, press and hold while applying power. Release button after Gateway powers on. The bootloader allows for firmware update recovery.

Reset to factory defaults - With power removed from the Gateway, press and hold while applying power, continue to hold the button for 30-seconds.

Operation

The PATRIoT Gateway is designed to support all remote 900MHz SignalFire nodes, making all remote sensor data available in Modbus format. This functionality allows for seamless integration and communication between various remote sensors and the central gateway.

Data Retrieval

The register data from remote sensor nodes can be accessed by requesting the remote node's Modbus ID and register address from that node's register map. The gateway will respond with the most recent copy of the data from the remote node. This ensures that the data is up-to-date and accurate, providing reliable information for monitoring and control purposes.


Data Timeout

To maintain data integrity and ensure that outdated information is not used, the gateway will automatically time-out data from a remote node if it stops receiving data from that node. This feature helps in identifying and troubleshooting communication issues with remote nodes, ensuring that only valid and current data is used in the system.


C1D2 Hazardous Location Installation

Installation of the PATRIoT Gateway in Class I, Division 2 (C1D2) hazardous locations shall be performed in accordance with the instructions and limitations defined in the PATRIoT Gateway Safety Manual (P/N 960-0120-11).

Dimensions



How To Order



1. Setup

The PATRIoT Gateway can be configured in one of three ways, via the ToolKit over the USB-C connection, via the ToolKit over the Ethernet connection, or all basic settings are available from a web browser using the Ethernet connection. Advanced features such as register remapping, Remote Shutdown configuration and MQTT/Sparkplug mapping must be done using the ToolKit software.

Default Settings

The default IP and user credentials are below.

IP Address:	192.168.1.100
Host Name:	PATRIoT-"MAC ADDRESS"
Modbus TCP Port:	502
SignalFire Toolkit Port:	10002
File Transfer port	10003
Web Config Username:	admin
Web Config Password:	signalfire

The SignalFire ToolKit port is user configurable, but the File transfer port will always be one higher than the configured ToolKit port. For example, if you change your ToolKit port to 1000, 1001 would be used as the file transfer port. Please make sure both ports are applied to any port forwards your network may require for full remote ToolKit capability.

1.1 Using the SignalFire Toolkit

The SignalFire Toolkit application can be downloaded at <https://www.signal-fire.com/signalfire-toolkit-software/>. After installation, launch the software and the main toolkit window will open:




Figure 1

USB-C Connection

After connecting the USB-C cable, select the PATRIoT Gateway in the drop-down list and click "Auto-Detect Device on COM Port." This will open the Gateway configuration window, where all settings can be configured.

Ethernet ToolKit Connection

To connect to the PATRIoT Gateway with the ToolKit over the Ethernet connection, first ensure that your PC is connected to the same network as the Gateway and is configured for the same IP address space. Then select the "PATRIoT Gateway" from the Select Device drop down list and click Open Device Window. Select "TCP", enter the IP address of the Gateway and click Open.



1.2 Web Browser Configuration

The final method of configuring the Gateway is via the PATRIoT's built-in web configuration application. This allows users to set basic settings, view the Gateway status, download log files and update firmware without the need for any special software. To access the web configuration page, enter the IP address of the PATRIoT Gateway in your web browser.

Note your browser may show a security warning, click "Advanced" and click proceed to connect to the Gateway



Your connection is not private

Attackers might be trying to steal your information from **10.1.10.213** (for example, passwords, messages, or credit cards). [Learn more about this warning](#)

NET:ERR_CERT_AUTHORITY_INVALID



[Turn on enhanced protection](#) to get Chrome's highest level of security

Advanced

Back to safety

1.3 Web and ToolKit Dashboard Overview

Upon logging into the PATRIoT Gateway web interface, the Dashboard provides a high-level summary of system and network status. This information is also available on the left side of the ToolKit window

System Status:

- Firmware Version: displays the firmware version of the PATRIoT
- System Time: Displays the current UTC time (e.g., 2025-07-29 15:44:52 UTC)
- System Uptime: Shows how long the system has been running since the last reboot

Network Status:

- Network Interface: Indicates whether the device is using a static IP or DHCP
- MAC Address: Unique hardware identifier
- Hostname: Device hostname
- IP Address: Current IP address
- Subnet Mask: Network mask
- Default Gateway: Router IP

Radio Status:

- Detected: Indicates if a radio module is detected
- Firmware: Displays radio firmware version (if available)
- Connected Nodes: Number of connected radio nodes
- Packets Per Minute: Number of Packets per minute received by the remote nodes, should be less than 60

Quick View:

This section provides a snapshot of key I/O and communication statuses:

- DHCP, NTP, MQTT: Show whether these services are active
- Radio Detected: Indicates radio module presence
- Port1, Port2, DIN1, DIN2, DOUT1, DOUT2: Status of digital and serial ports

1.4 PATRIoT Gateway and Firmware updates

Firmware updates for both the PATRIoT Gateway and the built-in radio can be performed over the USB Port using the SignalFire Toolkit.

Gateway Firmware update steps

1. Open the SignalFire Toolkit application.
2. Connect to the PATRIoT with the USB port and open the PATRIoT Gateway Window
3. Go to the **Update** menu and select **Update PATRIoT Firmware**.
4. The latest gateway firmware file will be selected by default.
5. Click **Start Upgrade**.

2. Radio Nodes Overview

The **Radio Nodes** tab provides a real-time view of all connected wireless nodes and their operational status. This is essential for monitoring signal strength, battery health, and firmware versions.

2.1 Table Columns Explained

Column	Description
Modbus ID	Unique identifier for each node on the Modbus network.
Node Type	Type of device (e.g., A2 HART, A2 Analog, WIOM, Flow Totalizer).
Node Name	User-defined or default name for the node.
RSSI (dBm)	Received Signal Strength Indicator. Higher (less negative) values indicate better signal.
Battery Voltage (V)	Current battery voltage of the node.
Check-in Interval (min)	How often the node checks in with the gateway.
TTL (min): Current/Max.	Time-to-live values showing how long the node remains active before timing out.
Mainboard Firmware	Firmware version of the node's mainboard.
Radio Firmware	Firmware version of the radio module. "(sleeping)" indicates the node is in low-power mode and will not act a repeater for other nodes. Devices not marked as sleeping will automatically act as repeater nodes in the network

SignalFire Telemetry PATRIOT Gateway | admin

Modbus ID	Node Type	Node Name	RSSI (dBm)	Battery Voltage (V)	Checkin Interval	TTL (min): Current/Max	Mainboard Firmware	Radio Firmware
5	A2 HART	A2HART	-34	3.643	60	7/7	0.92	2.52 (sleeping)
7	A2 Analog	A2Analog7	-83	3.447	60	7/7	0.92	2.50 (sleeping)
8	WIOM Mini-A	WIOM-Mini	-55	11.653	60	7/7	0.04	2.52
14	Flow Totalizer V2	FlowTotal	-44	3.400	60	7/7	1.18	2.51 (sleeping)
200	WIOM	WIOM200	-44	11.672	60	7/7	0.24	2.52
236	Sent MB	Sent236	-48	3.287	60	7/7	0.68	2.51 (sleeping)

When connected via the ToolKit, you can view the register data by double clicking on any of the connected remote nodes.

Radio Nodes | Radio Settings | Info | Network | Serial Ports | MQTT | SparkPlug | I/O | Modbus TCP | Bluetooth


Double-click a Row to View Registers Auto Refresh [Refresh List](#)

Modbus ID	Node Type	Node Name	RSSI (dBm)	Battery Voltage (V)	Checkin Interval	TTL (min): Current/Max	Mainboard Firmware	Radio Firmware	Configure
5	A2 HART	A2HART	-34	3.643	1 min	7/7	0.92	2.52 (sleeping)	<input type="checkbox"/>
7	A2 Analog	A2Analog7	-68	3.448	1 min	7/7	0.92	2.50 (sleeping)	<input type="checkbox"/>
8	WIOM Mini-A	WIOM-Mini	-54	11.659	1 min	7/7	0.4	2.52	<input type="checkbox"/>
14	Flow Totalizer V2	FlowTotal	-46	3.405	1 min	7/7	1.18	2.51 (sleeping)	<input type="checkbox"/>
200	WIOM	WIOM200	-42	11.672	1 min	7/7	0.24	2.52	<input type="checkbox"/>
236	Sent MB	Sent236	-45	3.282	1 min	7/7	0.68	2.51 (sleeping)	<input type="checkbox"/>

If one or more remote nodes are configured with the correct network settings, they will send their data to the gateway. Clicking **Refresh List** will populate the list with all connected remote nodes. The gateway displays the node type, node name (if it has been set), RSSI signal strength, check-in interval, the Time-To-Live (TTL), and the node's radio and main firmware versions.

The RSSI and TTL values are color coded (Green, yellow, orange, red) to indicate relative link quality of a node. The 'TTL Current' indicates the number of minutes remaining until the node is timed out of the gateway if no updates are received. The 'TTL Max' indicates the maximum TTL for that node and is equal to the node's check-in interval times 5 plus 2. The 'TTL Current' will reset to the 'TTL Max' each time an update is received from that node. The 'TTL Current' will decrease once a minute.


Double clicking on one of the nodes in the list will bring up additional detail including the register data from the remote node.



Remote Node Configuration


The SignalFire Gateway allows configuration changes to be made to any of the connected SignalFire remote nodes wirelessly.

To start a remote configuration session with a remote node, select the checkbox next to the node to configure.



If the device has a non-sleeping radio the remote configuration session will be ready immediately. If it is a sleeping device, you must wait for the node to either check-in or send a “beacon” so that it can be commanded into configuration mode. The Sentinel nodes send a beacon every two and a half minutes, while all other sleeping nodes send a beacon every five and a half minutes. When the device has entered a remote configuration session you will see a message indicating the device is ready. Click **Configure** to open the configuration window

Make any necessary changes and click the **Apply All Settings** button to save the changes. When finished with the configuration, close the configuration window and then click the **End** button in the Gateway window to end the session. The session will also automatically time-out after 15 minutes of inactivity and the Node will resume normal operation.



Example Remote Configuration Window

Further information on how to remotely configure a HART device through the ToolKit using PACTware can be found in the “Remote HART Sensor Configuration Manual”.

Remote Modbus Sticks and Sentinel-Modbus (non-sleeping radio only) Nodes

Remote nodes, that have been pre-configured, forward their set of registers to the Modbus gateway on a pre-defined schedule (1 minute to 5 minutes is typical). The register data is then buffered in the gateway and is available to be read by the RTU at any time.

If a Modbus request is received by the gateway for a Modbus ID and address for which buffered data does not exist, but the Modbus ID is known, the Modbus request will be forwarded to the remote Modbus node over the SignalFire network. The response is returned to the RTU.

If a request for multiple registers is issued by the RTU, and if the gateway does not have all registered data buffered, an exception will be returned. The system will not combine buffered and transparent data within a single Modbus response.

3. Radio Settings

The **Radio Settings** page allows you to configure the wireless communication parameters of the PATRIoT Gateway's internal radio module. This is essential for ensuring secure and reliable communication with remote nodes.

3.1 Radio Status

This section provides a quick overview of the radio module's current state:

- **Radio Module:** Indicates whether the radio hardware is detected
- **Firmware Version:** Displays the current firmware version of the radio
- **Node Address:** Unique identifier for the radio node (e.g., 98787)

3.2 Device Settings

These settings define how the radio communicates within the network:

Setting	Description
Network	Configures the Radio Network Setting
Network Group	Configures the Radio Network Group Setting
Encryption Key	Security key used to encrypt radio communications
Hide Encryption Key	Toggle to hide the encryption key and make it unreadable
Corporate ID	For legacy systems not using encryption
Erase and Reset Radio to Defaults	Toggle to factory reset the radio settings

 **Note:** Always ensure the Radio Network, Radio Network Group and Encryption key is consistent across all devices in the same network to maintain secure communication.

3.3 Save Changes

After making any modifications, click the **Save** button at the bottom right to apply the new settings.

The screenshot shows the SignalFire Telemetry PATRIoT Gateway web interface. The top navigation bar includes the SignalFire logo, the page title "SignalFire Telemetry PATRIoT Gateway", the user "admin", and a refresh button. A left sidebar contains a menu with items: Dashboard, Radio Nodes, Radio Settings (highlighted), Info, Network Settings, Serial Ports, MQTT, Sparkplug, I/O, Modbus TCP, Logs, User Settings, and Support. The main content area is divided into two sections: "Radio Status" and "Device Settings".

Radio Status

Radio Module:	<input checked="" type="radio"/> Detected
Firmware Version:	2.50
Node Address:	98787

Device Settings

Network:	<input type="text" value="0"/>
Network Group:	<input type="text" value="0"/>
Encryption:	<input checked="" type="checkbox"/>
Encryption Key:	<input type="text" value="PATRIoTQA"/>
Hide Encryption Key:	<input type="checkbox"/>
Corporate ID:	<input type="text" value="0"/>
Erase and Reset Radio to Defaults:	<input type="checkbox"/>

A "Save" button with a floppy disk icon is located at the bottom right of the Device Settings section.

This is a close-up of the Radio Settings form. It contains the following fields:

Network	<input type="text" value="0"/>
Network Group	<input type="text" value="0"/>
Encryption	<input checked="" type="checkbox"/>
Encryption Key	<input type="text" value="PATRIoTQA"/>
Hide Encryption Key	<input type="checkbox"/>
Corporate ID	<input type="text" value="0"/>

4. Info Tab

The **Info** tab provides detailed diagnostics, configuration options, and maintenance tools for the PATRIoT Gateway. It is divided into five key sections:

4.1 Device Status

This section displays real-time system metrics and firmware details

4.2 Device Actions

These buttons allow you to manage firmware and restart the device:

1. **Reboot Device** – Immediately restarts the gateway.
2. **Upload Firmware to Gateway** – Allows manual firmware upload from a local file.
3. **Download Firmware From Update Server** – Automatically fetches the latest firmware from the SignalFire update server.

From the SignalFire ToolKit these options are in the **Updates** and **Tools** menu.

4.3 Device Settings

Customize the gateway's identity and communication ID:

- **Device Name:** Editable field (default: *SignalFire PATRIoT Gateway*)
 - **Gateway Modbus ID (241–255):** Numeric input (e.g., 247)
 - **Erase Name & Modbus and Set to Defaults:** Toggle switch to reset these fields to factory defaults.
-

4.4 Clock Setting

Manually adjust the system clock:

- **Current Date and Time:** Editable fields (e.g., *07/29/2025 08:34 PM*)
 - **Save Button:** Applies the new time settings.
-



4.5 Reset to Factory Defaults

To perform a full factory reset:

1. Type the phrase: **Factory Reset Erase Everything**
2. Click the **Confirm Reset** button

From the SignalFire ToolKit this option is in the **Tools** menu.

⚠ Warning: This action will erase all configuration data and restore the gateway to its original factory state.



5. Network Settings

The **Network Settings** tab allows you to configure Ethernet connectivity, DNS, NTP synchronization, and web access for the PATRIoT Gateway.

5.1 Network Status

This section displays the current state of the Ethernet interface

5.2 Network Time Protocol (NTP) Status

This section displays the current state of the Time server

5.3 Web Status

- **Web Enabled:** Indicates that the web interface is currently active.

5.4 Editable Network Settings

Setting	Description
Enable Networking	Toggle to activate/deactivate the Ethernet network interface
DHCP	Toggle to enable dynamic IP assignment
Static IP Address	Manually assigned IP
Subnet Mask	Network mask
Gateway Address	Router IP
DNS Server 1 & 2	Primary and secondary DNS servers

6. Serial Port Settings

The **Serial Ports** tab allows you to configure the communication parameters for the gateway's physical serial interfaces. These settings are essential for integrating with Modbus RTU devices or other serial-based equipment.


6.1 Port 1 and Port 2 Configuration

Setting	Description
Enable	Toggle switch to activate Port
Mode	Electrical interface type (e.g., <i>RS485</i> , <i>RS232</i> , <i>RS485 with termination resistor</i>)
Protocol	Communication Protocol (e.g., <i>Modbus RTU Server</i> , <i>Modbus RTU Client</i>)
Baud Rate	Transmission speed (e.g., <i>9600 bps</i>)
UART Mode	Data format (e.g., <i>8N1</i> = 8 data bits, No parity, 1 stop bit)


Tip: Ensure that the baud rate and UART mode match the settings of the connected Modbus devices to avoid communication errors.

6.2 Reset and Save Options

- **Erase Port Settings and Set to Defaults:** Toggle switch to restore factory defaults for both ports.
- **Save Button:** Applies all changes made to the serial port configurations.



To configure the Modbus polling click on the "View/Edit Modbus RTU Client Polling List"



In this table fill out Register Name, Modbus ID, Register Address, Register Type and Datatype for each register to poll.

The Address Picker will allow you to quickly configure Modbus Polling for the SignalFire MIOM, IO1, and ModQ Modbus devices.

Note that care must be taken to ensure that each Modbus ID polled is unique to the PATRIoT Gateway and does not overlap with any wireless devices also connected to the Gateway.

6.5 Output Module Mode

The PATRIoT Gateway supports the SignalFire Analog/Relay Output module (8AO2DO) and the Digital Output Module (12DO). To use the output modules, select "Output Module" for one of the serial ports, only one of the two serial ports can be configured in Output Module Mode at a time.

Wiring is as follows:

PATRIoT Gateway Serial Port	Output Module
A/TX	ORANGE
GND	BLACK

The Analog outputs can be configured from the "Analog Output Modules" in the settings menu on the ToolKit, while the relay and digital outputs can be controlled using the Gateway's RSD Logic. See the respective output module manual for additional details.

7. MQTT Configuration

The **MQTT** tab allows you to configure how the PATRIoT Gateway communicates with MQTT brokers for telemetry data transmission. This includes connection status, broker settings, and security options.

7.1 MQTT Status (Left Panel)

Field	Description
State	Indicates current connection status (e.g., <i>CONNECTED</i>)
Broker Hostname	DNS name of the connected broker
Broker Address	IP address or URL of the broker
TLS Encryption	Whether Transport Layer Security is enabled
TLS Certificate	Certificate used for secure communication
QoS (Quality of Service)	Level of message delivery assurance
Keepalive Interval	Time interval (in seconds) to maintain connection with broker

7.2 MQTT Client Enable Settings (Right Panel)

You can configure up to three MQTT brokers. The PATRIoT will only connect to one broker at a time, but if the connection is lost it will move to the next broker in the list in a round-robin fashion.

Each broker has the following fields:

Setting	Description
Hostname	Broker's DNS name or IP address
Port	Communication port (typically 1883 for non-TLS, 8883 for TLS)
Client ID	Unique identifier for the gateway on the broker
QoS	Message delivery level (0, 1)
Keepalive Interval	Time in seconds to keep the connection alive
TLS Level	Security level for encrypted communication
Security Tag	Optional tag for managing certificates or credentials
Username	Username for the MQTT connection
Password	Password for the MQTT connection

7.3 Reset and Save Options

- **Erase and Reset MQTT to Defaults:** Restores all MQTT settings to factory defaults.
- **Save Button:** Applies all changes made to the MQTT configuration.

 **Tip:** Always verify TLS and certificate settings when connecting to secure brokers to ensure encrypted data transmission.





Figure 2



8. Sparkplug Configuration

The **Sparkplug** tab is used to configure the gateway's behavior when publishing telemetry data using the Sparkplug B protocol over MQTT. This is particularly useful for integration with SCADA systems and IIoT platforms like Ignition.

8.1 Sparkplug Status

Field	Description
Server State	Indicates the current connection status (e.g., <i>ONLINE</i>)
Server State Elapsed	Duration the server has been online
Server Host ID	Identifier of the MQTT broker or host
Namespace	Sparkplug namespace (e.g., <i>spBv1.0</i>)
Group ID	Logical group for Sparkplug messages
Edge Node ID	Unique ID for this gateway (e.g., <i>PG000015</i>)
Birth/Death Sequence	Sequence number for lifecycle events
Publish Sequence	Sequence number for data messages
Report Count	Number of published message

8.2 Sparkplug Settings


Setting	Description
Group ID	Logical group name for Sparkplug messages
Edge Node ID	Unique identifier for the gateway (e.g., <i>PG000015</i>)
Require Primary Host ONLINE to Publish	Toggle to restrict publishing unless the primary host is online (enabled)
Primary Host ID List	Optional list of host IDs that must be online before publishing
Report Interval (Sec)	Frequency of data publishing in seconds (e.g., <i>300</i>)

Erase and Reset Sparkplug to Defaults: Toggle to restore default Sparkplug settings

8.3 Save Changes

Click the **Save** button to apply any changes made to the Sparkplug configuration.

 **Tip:** Ensure the Group ID and Edge Node ID are unique within your Sparkplug network to avoid data collisions.



The screenshot displays the SignalFire Telemetry PATRIot Gateway admin interface. On the left is a navigation menu with options: Dashboard, Radio Nodes, Radio Settings, Info, Network Settings, Serial Ports, MQTT, Sparkplug (selected), I/O, Modbus TCP, Logs, User Settings, and Support. The main content area is divided into two sections: 'SparkPlug Status' and 'SparkPlug Settings'. The 'SparkPlug Status' section shows: Server State: ONLINE, Server State Elapsed: 19:46:59, Server Host ID: node-red, Namespace: spBv1.0, Group ID: patriot, Edge Node ID: PG000015, Birth/Death Sequence: 7, Publish Sequence: 8, and Report Count: 1640. The 'SparkPlug Settings' section includes: Group ID: patriot, Edge Node ID: PG000015, Require Primary Host ONLINE to Publish: (toggle checked), Primary Host ID List: (empty), Report Interval (Sec): 300, and Erase and Reset Sparkplug to Defaults: (toggle unchecked). A 'Save' button is located at the bottom right of the settings panel.

8.4 Reported Metrics

The Toolkit also displays a list of the reported Sparkplug metrics if configured.

SparkPlug Status

Server State	Online (1 day, 19:05:24)
Server Host ID	node-red
Namespace	spBv1.0
Group ID	patriot
Edge Node ID	PG000015
Birth/Death Sequence	7
Publish Sequence	20
Report Count	1920

SparkPlug Settings

Group ID	patriot	Help
Edge Node ID	PG000015	Help
Require Primary Host ONLINE to Publish	<input checked="" type="checkbox"/>	Help
Primary Host ID List		
Report Interval (Sec)	300	

[Sparkplug MQTT Topic & Payload Specification Rev 3.0.0](#)

Open Sparkplug Map

Update Reported Metrics

Set to Defaults

Refresh Apply

8.5 Configuring Sparkplug Using SignalFire Toolkit

Creating a Sparkplug Map in PATRIoT Gateway

The PATRIoT gateway can publish all measurements using the MQTT/Sparkplug standard. In order to publish to MQTT the connection to the MQTT broker must be established, and all data to publish must be added to the Sparkplug map.


The following steps are necessary to publish the measurements, also known as MQTT Tags.

Configure MQTT Settings	<p>This step is to setup the gateway to publish the data to an MQTT Broker. The MQTT Broker is hosted by SignalFire when using the SignalFire Cloud and it is already setup in the PATRIoT gateway. A subscription to the SignalFire Cloud is necessary. Contact SignalFire to obtain a subscription</p> <p>When using a different broker, it is necessary to setup the gateway's MQTT communication settings so that the PATRIoT can successfully connect to the MQTT Broker.</p>
Configure Sparkplug Settings	<p>This step is to setup the Node Name as it will appear to a Broker and a Subscriber. It is also to setup how often the data is sent to the broker (Report Interval).</p> <p>When using a broker other than SignalFire's, additional setup is necessary for the GroupID and EdgeNodeID. The Sparkplug specification contains information on how to use the GroupID and EdgeNodeID.</p>

Create A List Of Tags To Be Published	This is the step to associate the PATRIOT's measurements or output signals with corresponding Sparkplug Tags. Using the SignalFire Toolkit Software, the tags are created using the Address Picker. When connecting to a broker, these tags will be published for a subscriber to use.
---------------------------------------	--


Step 1: Access the Sparkplug Section

Open the PATRIoT Gateway window. Click on the Sparkplug section to begin the configuration.




Step 2: Configure the PATRIoT Gateway Name

Change the Node name of the PATRIoT Gateway. This name will be presented to the MQTT Sparkplug host.



Step 3: Set the Report Interval

Adjust the report interval for how often MQTT tags will be published to the Sparkplug-ready host.




Step 4: Create the Sparkplug Map

You can use a CSV file to create the list of Sparkplug Tags. Click on EXPORT CSV to get a template to use. Then fill in the Template and import into the table by clicking IMPORT CSV.


or

Click on the Address Picker to open the table that displays the tags generated from Modbus IDs and addresses available at the Gateway. From there you can select the Modbus IDs and associated tags. See Step 5.




Step 5: Use the Address Picker

Click on the address picker to view all available Modbus IDs connected to the PATRIot Gateway.




Step 6: Select a Modbus ID

Click on a Modbus ID to view relevant Modbus tags associated with it.



Step 7: Choose Modbus Registers

Select one or more Modbus registers of interest.
Click 'Apply' to add them as MQTT tags.




Step 8: Write the New Map

Modify the Tag Name as needed. The default Tag Name will be the Modbus Registers Name for SignalFire Devices. Note that the forward slash can be used to organize the tags in folders on the MQTT host.

Click 'Write' to save the new map to the PATRIoT Gateway.

The row will be colored Yellow for pending changes.


Verify that the current value of the Modbus register appears as an MQTT tag value.



Step 9: Enter Units for MQTT Tags


Registers added from SignalFire nodes will have the default units already filled in. For data coming from Modbus devices, type in the units for each MQTT tag in the designated column.

Click 'Write' again to save the units.



Step 10: Finalize the Sparkplug Map

Review the Sparkplug map to ensure all Modbus registers from various Modbus IDs are correctly added.



9. I/O Configuration

The **I/O** tab provides real-time status monitoring and manual control of the gateway's digital input and output channels. This is useful for diagnostics, remote control, and integration with external devices.

9.1 I/O Status

This panel displays the current state of each digital input and output:


Channel	Status
DIN1	Open
DIN2	Open
DOUT1	Open
DOUT2	Open

9.2 I/O Settings

This panel allows manual control of the digital outputs:

Output	Control
DOUT1	Toggle switch (currently OFF)
DOUT2	Toggle switch (currently OFF)


Save Button: Applies any changes made to the output states.




9.3 I/O Wiring

Digital Inputs


The digital outputs may be connected to the PATRIoT's DIN1 and DIN2 terminals as shown in the following diagrams:



Dry Contact Connection



Open Collector Connection




Voltage Pulse Connection

Digital Outputs

The PATRIoT Gateway has two local open collector outputs. These can be controlled like any other digital output using the RSD logic table or writing to registers on the Gateway (see register table). They can also be toggled manually using the I/O Tab.

The open collector outputs can control a relay when wired as shown below.



Note: The digital outputs on the gateway have built in protection and can drive relays and inductive loads directly.

10. Modbus TCP Configuration

The **Modbus TCP** tab allows you to monitor and configure the gateway's Modbus TCP server, which enables communication with SCADA systems and other Modbus-compatible clients over Ethernet.

10.1 Modbus TCP Status

This panel provides real-time metrics on server activity:

Metric	Description
Server State	Indicates if the Modbus TCP server is active (e.g., Running)
Active Connections	Number of currently connected clients (e.g., 0)
Total Connections	Total number of connections since startup
Total Closed	Number of connections that were closed normally
Total Dropped	Number of connections dropped due to errors or timeouts
Total PDU In	Protocol Data Units received
Total PDU Out	Protocol Data Units sent
Total PDU Exception	Number of Modbus exception responses sent
Total PDU Error	Number of Modbus error responses
Total PDU Dropped	Number of PDUs dropped due to errors or timeouts

10.2 Modbus TCP Settings

Setting	Description
Server Enabled	Toggle to activate or deactivate the Modbus TCP server
Default Port	Standard Modbus TCP port (always available if Modbus-TCB is enabled)
Additional Port	Optional secondary Modbus-TCP port
Response Timeout (ms)	Time to wait for a response before timing out

10.3 Reset and Save Options

- **Erase and Reset Modbus TCP to Defaults:** Checkbox to restore factory settings.
- **Save Button:** Applies all changes made to the Modbus TCP configuration.

- Dashboard
- Radio Nodes
- Radio Settings
- Info
- Network Settings
- Serial Ports
- MQTT
- Sparkplug
- I/O
- Modbus TCP**
- Logs
- User Settings
- Support

Modbus TCP Status

Server State:	Running
Active Connections:	0
Total Connections:	0
Total Closed:	0
Total Dropped:	0
Total Pdu In:	0
Total Pdu Out:	0
Total Pdu Exception:	0
Total Pdu Error:	0
Total Pdu Dropped:	0

Modbus TCP Settings

Server Enabled:

Default Port:

Additional Port:

Response Timeout:

Erase and Reset Modbus TCP to Defaults:

[Save](#)

Modbus TCP Status

Server State	Running
Active Connections	0
Total Connections	0
Total Closed	0
Total Dropped	0
Total Pdu In	0
Total Pdu Out	0
Total Pdu Exception	0
Total Pdu Error	0
Total Pdu Dropped	0

Modbus TCP Settings

Server Enabled

Default Port

Additional Port

Response Timeout (ms)

[Show Modbus TCP Debug](#)

11. EtherNet/IP Configuration

The PATRIoT Gateway can be configured to act as an EtherNet/IP Adapter allowing data to be mapped so it can be read by an EtherNet/IP Scanner like a PLC. The **EtherNet/IP** tab allows you to monitor and configure the gateway's EtherNet/IP Adapter settings, which enables communication with SCADA systems and other EtherNet/IP over Ethernet.

11.1 Enabling EtherNet/IP

Enable the EtherNet/IP Adapter using the SignalFire ToolKit. The PATRIoT Gateway supports either EtherNet/IP or Modbus-TCP, but not both simultaneously. Changes to the EtherNet/IP Adapter mode require a reboot before they will take effect

11.2 CIP Object Model Overview

The PATRIoT Gateway implements the standard EtherNet/IP CIP object set required for ODVA conformance. These objects allow EtherNet/IP scanners (such as Allen-Bradley CompactLogix/ControlLogix PLCs) to identify the device, establish sessions, exchange I/O data, and read configuration information.

Supported CIP Objects

Object	Class ID	Description
Identity Object	0x01	Reports Vendor ID, Device Type, Product Code, Firmware Revision, Serial Number, and Device Name.
Message Router	0x02	Routes CIP service requests to the correct object class instance.
Assembly Object	0x04	Implements the Input and Output Assemblies used for Class 1 cyclic I/O connections.
Connection Manager	0x06	Manages Class 1 (cyclic) and Class 3 (explicit) connections. Supports up to 2 Class-1 I/O connections and 3 Class-3 connections.
TCP/IP Interface	0xF5	Provides IP addressing information such as IP address, subnet mask, and gateway.
Ethernet Link	0xF6	Reports link status, duplex mode, and port speed.

Identity Object Details

The following attributes are populated at runtime:

Vendor ID: 1829 (SignalFire Wireless Telemetry)

Device Type: Generic EtherNet/IP Adapter

Product Code: SignalFire PATRIoT Gateway

Revision: Revision of the EDS File

11.3 Adapter Connection Capabilities

Supported Connection Types

- **Class 1 (I/O) Connections**

The PATRIoT Gateway supports:

- 2 simultaneous Class 1 cyclic I/O connections
- One scanner may establish an Exclusive Owner connection
- Additional scanners may connect using Input-Only or Listen-Only (if the scanner supports these modes)

- **Class 3 (Explicit Messaging)**

Supports up to 3 sessions, used for browsing objects, reading attributes, and diagnostics.

Requested Packet Interval (RPI)

Supported RPI range:

- 10 ms minimum
- 1000 ms maximum
- Recommended RPI: 100–500 ms

Unicast / Multicast Behavior

- All Class-1 I/O connections operate using unicast packets.

11.2 EtherNet/IP Assembly Definitions

The PATRIoT Gateway exposes multiple read (input) and write (output) assemblies. Each assembly is a static-size block of data defined as follows:

Input Assemblies (Gateway → PLC)

Instance	Hex	Description	Size	Capacity
100	0x64	Read Register Mapping Table 1	496 bytes	248 registers
101	0x65	Read Register Mapping Table 2	496 bytes	248 registers

Output Assemblies (PLC → Gateway)

Instance	Hex	Description	Size	Capacity
116	0x74	Write Register Mapping Table 1	496 bytes	248 registers
117	0x75	Write Register Mapping Table 2	496 bytes	248 registers

Data Representation Rules

- All register data is stored as **16-bit words**.
- 32-bit types consume **two consecutive words**.
- Boolean values use **full 16-bit words**
- Little Endian byte order.-endian byte order.

11.3 Network and Port Requirements

The EtherNet/IP Adapter requires:

Required TCP/UDP Ports

Purpose	Port	Protocol
CIP explicit messaging	44818	TCP & UDP
CIP cyclic I/O transport	2222	UDP

Network Behavior

- Requires gateway and PLC on the same IP subnet unless routed.
- Static or DHCP addressing supported.
- No multicast group joining required due to unicast-only I/O

11.4 Rockwell Automation Configuration (Studio 5000 Using EDS File)

The PATRiOT Gateway is designed to integrate with Rockwell Automation PLCs using a device-provided EDS file, eliminating the need for manual Generic Ethernet Module configuration. When the EDS file is installed, Studio 5000 automatically recognizes the PATRiOT Gateway, including its supported EtherNet/IP assemblies and data sizes.

Prerequisites

- EtherNet/IP Adapter is enabled on the PATRiOT Gateway
- Gateway and PLC are on the same Ethernet network and subnet

Downloading and Installing the PATRiOT EDS File

The PATRiOT Gateway serves its EDS file directly from the device using the EtherNet/IP File Object. This allows the EDS file to be downloaded automatically through Rockwell tools.

1. Open RSLinx Classic or Studio 5000.
2. Browse the Ethernet network until the PATRiOT Gateway is visible.
3. Right-click on the PATRiOT Gateway.
4. Select Upload EDS File from Device.
5. Follow the prompts to complete the EDS registration.
6. Restart Studio 5000 after the EDS installation completes.

Once installed, the PATRiOT Gateway will appear as a recognized device in the Rockwell hardware catalog.

Adding the PATRIoT Gateway to the I/O Configuration

After the EDS file is installed, the PATRIoT Gateway can be added to the PLC project like any standard EtherNet/IP adapter.

1. Open the PLC project in Studio 5000.
2. Go Offline.
3. In the I/O Configuration tree, right-click the Ethernet bridge.
4. Select Add Module.
5. Choose SignalFire PATRIoT Gateway from the device list.
6. Enter the IP Address of the gateway.
7. Set Electronic Keying to *Compatible* (recommended).
8. Accept the default assembly instances and sizes provided by the EDS file.
9. Click OK, then download the project to the PLC.

Studio 5000 automatically configures:

- Input Assembly instance(s)
- Output Assembly instance(s)
- Assembly sizes (based on fixed 248-word / 496-byte blocks)

No manual entry of assembly numbers or data sizes is required.

Verifying Communication

The EtherNet/IP connection is considered successfully established when:

- The PLC is **Online**
- The PATRIoT Gateway appears under the Ethernet tree
- No yellow warning triangles are present
- Module status shows **Running**

If the module does not appear or shows a warning:

- Verify the EDS file is installed
- Confirm IP address and subnet
- Confirm EtherNet/IP is enabled and the gateway has been rebooted after enabling

Important Notes About Tags and Data Mapping

- The EDS file defines assembly instances and sizes only
- The actual data layout inside the assemblies is defined by the user in the SignalFire ToolKit
- PLC tags must be created to match the configured Modbus register mappings
- Because mappings are user-defined, tag names and data types are not auto-generated by the EDS file

This design allows maximum flexibility while still providing a plug-and-play EtherNet/IP device experience.

11.5 Data Assembly Mapping

The PATRIoT Gateway uses EtherNet/IP Data Assemblies to exchange data with an EtherNet/IP Scanner such as a PLC. Data is mapped from internal gateway registers into fixed-size EtherNet/IP assemblies using the SignalFire ToolKit.

To configure EtherNet/IP data mapping, open the EtherNet/IP tab in the SignalFire ToolKit and select **View/Edit EtherNet/IP Data Assembly Mappings**. This opens the EtherNet/IP Data Assembly Mapping editor.

Each assembly represents a contiguous block of data that the PLC reads from or writes to the gateway.

Offset	Name	Modbus ID	Address	Register Type	Datatype	Value
0	Counter (state)	7	1003	Holding Register (...)	Bit Pos 0	0
2	Counter (counts)	7	1004	Holding Register (...)	UINT32	0
4		7	1005	Holding Register (...)	UINT32	
6	RSSI (dBm)	7	65531	Holding Register (...)	INT16	-65
8	Battery Voltage (mV)	7	65532	Holding Register (...)	UINT16	3657
10				Holding Register (...)	UINT16	
12				Holding Register (...)	UINT16	
14				Holding Register (...)	UINT16	
16				Holding Register (...)	UINT16	
18				Holding Register (...)	UINT16	
20				Holding Register (...)	UINT16	
22				Holding Register (...)	UINT16	
24				Holding Register (...)	UINT16	
26				Holding Register (...)	UINT16	
28				Holding Register (...)	UINT16	
30				Holding Register (...)	UINT16	

Selecting a Data Assembly

At the top of the mapping window, select the desired EtherNet/IP assembly from the drop-down list.

Assemblies are divided into:

- **Read (Input) Assemblies** – Data sent *from the gateway to the PLC*
- **Write (Output) Assemblies** – Data sent *from the PLC to the gateway*

Example:

- **Instance 100 (0x64) – Read Modbus Data Block 1**
- **Instance 116 (0x74) – Write Modbus Data Block 1**

Each assembly is configured independently. Changes made to one assembly do not affect other assemblies.

Assembly Size and Layout

Each EtherNet/IP data assembly supports:

- Up to 495 words (16-bit words)
- Data is laid out sequentially by offset

The Offset column represents the starting word position within the assembly. Offsets increase automatically based on the selected data type.

Note: Although the EtherNet/IP protocol supports byte-level access, the PATRIoT Gateway maps all data in 16-bit word increments.

Mapping Methods

Data can be mapped into an assembly using one of two methods:

Address Picker (Recommended)

The Address Picker allows the user to browse and select available gateway registers without manually entering Modbus details.

To use the Address Picker:

1. Click Address Picker
2. Select the desired device or gateway data source
3. Choose the register or point to map
4. The Modbus ID, address, register type, and data type are populated automatically

This method reduces errors and is recommended whenever possible.

Manual Entry

Advanced users may manually enter mapping details by specifying:

- Modbus ID
- Register Address
- Register Type
- Data Type

This method is useful for third-party Modbus devices or custom register layouts.

PLC Considerations

- The PLC reads or writes the entire assembly, regardless of how many entries are mapped
- PLC tag definitions must match the order and size of mapped data
- Assembly contents are user-defined and may differ between gateways-defined and may differ between gateways
- The EDS file defines assembly size and instance numbers, not internal data layout

12. Logs

The **Logs** tab provides access to diagnostic and operational logs that are essential for troubleshooting, system auditing, and performance analysis. From the ToolKit logs are available from the **Tools** menu.

12.1 Log Categories


Log Type	Description
Event Logs	Captures system-level events such as reboots, configuration changes, and alerts.
Node Logs	Records activity and communication from connected radio nodes.
System Log File	Contains detailed system diagnostics and runtime information.

Each category includes a link to:

- **Download Most Recent [Log Type]** – Retrieves the latest log file for offline review.

12.2 Individual Log Access

Below the main categories, there are links to open specific logs directly in the browser



12.3 Accessing Logs from the ToolKit

The PATRIoT Gateway keeps an internal log of events that can be useful for troubleshooting.

The event log can be viewed from the gateway window of the ToolKit from the Tools Menu. The gateway log events such as reboots, remote nodes joining/timing out, local RSD control events, remote configuration sessions, firmware updates, and more.

The Node Statistics tab shows information reported every four hours from Sentinels, Scouts, and Flow Totalizers to the Gateway.

Saving the Gateway Log

There is a 'Email Logs To Tech Support' button in the upper right hand corner of the log file window. It will automatically save all the log entries, statistics and open a window to email SignalFire support with the files attached using your default email client. Alternatively, you can save the log to a file to share with SignalFire Tech Support.

13. User Settings


The **User Settings** tab allows administrators to manage account security by updating the login password for the web interface.

In the ToolKit the password setting is in the **Settings** menu.

13.1 Change Password

To update your password:


1. **Enter Your Current Password** – Required to authorize the change.
2. **New Password** – Enter your desired new password.
3. **Confirm New Password** – Re-enter the new password to confirm.
4. **Save Button** – Click to apply the password change.



14. Remote Shutdown (RSD)

The SignalFire Gateway supports **Internal Logic Control** capability which enables the Gateway to control output relays on any SignalFire device with Digital Outputs including the RSD stick, WIOM, WIOM-Mini, Gateway Output modules and the Gateway's built in DO's. The PATRIoT Gateway supports a maximum of 128 logic rules for remote shutdown.

The PATRIoT Gateway receives data from multiple remote nodes. It can use the data from those remote nodes to set the relay output on one or more remote relays. An example of the topology is shown in the following figure:



14.1 RSD Configuration

From the Gateway configuration window within the SignalFire Toolkit, go to the **Settings** menu and select **Remote Shutdown Settings**. This will open the RSD configuration window.

Source Value

The 'Source Value' section is used to select the source register for the logic rule.

Source Value						
	Modbus ID	Register Address	Node Name	Register Type	Datatype	Current Register Value
▶ 1	11	2005	A2HART11	Holding ...	FLOAT	88.45174
2				Holding ...	UINT16	Unknown
3				Holding ...	UINT16	Unknown
4				Holding ...	UINT16	Unknown
5				Holding ...	UINT16	Unknown
6				Holding ...	UINT16	Unknown
7				Holding ...	UINT16	Unknown
8				Holding ...	UINT16	Unknown
9				Holding ...	UINT16	Unknown
10				Holding ...	UINT16	Unknown
11				Holding ...	UINT16	Unknown
12				Holding ...	UINT16	Unknown

Modbus ID – The Modbus ID of the source node.

Register Address – Enter the register address for the data to use for the logic, or manually enter the Address Picker to automatically populate.

Node Name – This will be populated with the configured Node Name

Register Type – The correct register data type will be automatically selected if the Address Picker is used, if the address is manually entered select the correct data type here.

Current Register Value – Displays the value of the selected source data register. Clicking the **Update** button will refresh this value after the table has been saved to the Gateway

14.2 Relay Control Logic

The 'Relay Control Logic' section is used to set the trigger thresholds for the selected source data register.

Relay Control Logic				
Run System (Energize Relay) when...	Value	System (De-energize Relay) when...	Value	Number of Readings
Greater than	14	Less than	10	3
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1

Run System (Energize Relay) – Select the logic operand to use for the “energize” logic evaluation.

Value – The value that the relay will be energized. Note that the energized state is the normal “operating” state of the relay.

Shutdown System (De-Energize Relay) – The logic operand to use for the “de-energize” logic evaluation. This will automatically be the opposite of the selection for the energize case. Note that the de-energized state is the SAFE state of the relay.

Value – The value that the relay will be de-energized. Note that the de-energize state is the “safe” state of the relay.

Number of Readings – This field contains the number of check-in packets that must be received in a row that are above (or below) the logic threshold for the de-energize condition. This is useful so that a single (possibly a glitch) reading does not cause a shut-down. The default is 1 where each check-in will cause the rule to be evaluated and acted on. A single reading that satisfies the run system (energize) condition will cause the relay to energize.

14.3 Destination Relay

Destination Relay		
Modbus ID	Relay Channel	Current Relay State (readonly)
10	1	De-energized
0	1	Unknown

Modbus ID – The Modbus ID of the remote relay node (RSD Stick, WIOM Module Etc.) or the Modbus ID of the Gateway (default 247) for the local digital outputs or attached Gateway output modules.

Relay Channel – Select the relay or digital output channel to switch

Current Relay State – Shows the last value of the relay or digital output as reported to the gateway. Clicking the Update button will refresh this value.

After filling out the table click **Write to PATRIoT** to store the setting in the Gateway.

Relay Pulse

Destination relays can be configured to pulse instead of being permanently energized or de-energized. To do so, in the **Relay Channel** drop-down menu, select the same relay but in "(Pulse)" mode. Specify whether to pulse during run or shutdown, and specify the pulse duration.

Destination Relay			Relay Pulse	
Modbus ID	Relay Channel	Current Relay State (readonly)	Pulse Relay on...	Pulse Time (sec)
10	1 (Pulse)	De-energized	Run	3

14.4 RSD Table Example

Line 1 has been configured with a source data node as a Sentinel-Analog with the loop current (in μA) as the selected register. The relay will energize when the loop current is above $9000\mu\text{A}$ (9mA) and de-energize when the loop current is below $8000\mu\text{A}$ (8mA). Note that this configuration has a $1000\mu\text{A}$ (1mA) hysteresis factor.

Remote Shutdown Settings

Remote Shutdown settings with the same Destination Relay will ALL need to meet the Run System (Energize) condition in order to run the system

	Source Value						Relay Control Logic				Destination Relay			
	Modbus ID	Register Address	Node Name	Register Type	Datatype	Current Register Value	Run System (Energize Relay) when...	Value	Shutdown System (De-energize Relay) when...	Value	Number of Readings	Modbus ID	Relay Channel	Current Relay State (readonly)
1	238	3001	Sent238	Holding R...	UINT16	10791	Greater Than	9000	Less Than	8000	1	247	1	Energized
2	7	1003	A2Analog7	Holding R...	BIT POS 0	0	Equal To	0	Equal To	1	1	247	1	Energized
3	239	4005	Sent239	Holding R...	FLOAT	27.14632	Greater Than	25	Less Than	3.05	1	247	1	Energized
4	237	3012	Sent237	Holding R...	BIT POS 0	0	Equal To	0	Equal To	1	1	247	1	Energized
5				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
6				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
7				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
8				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
9				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
10				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
11				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
12				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown
13				Holding R...	UINT16	Unknown	Greater Than		Less Than		1		1	Unknown

Address Picker RSD Enabled Failsafe Enabled - Missing Device or Register results in Relay being De-energized

Clear Latch De-energize - Requires RTU to Re-energize Relay via Modbus Coil Write

Save to File Load from File Read PATRIoT Write to PATRIoT

In this example all 4 source nodes are assigned to the same destination Modbus ID and relay channel so the following statement applies:

If more than one rule is assigned to the same destination RSD Stick and relay channel, then all the rules must meet the energize condition for the remote relay to be energized. In other words, the RSD table logic is a Boolean AND.

Alternatively, this means that if any one of the four source node's logic results in the "de-energize" condition being true the relay will be de-energized (safe).

14.5 RSD Event log

The RSD events will be stored in the gateway internal event log which can be read using the ToolKit. Additionally, a basic RSD event log containing the last 5 RSD events is available to be read via Modbus from registers 7000-7024. See the Modbus register map for details. The Modbus event log is not maintained through gateway resets.

14.6 Additional RSD Options

There are three check boxes for additional logic options.

RSD Enabled Failsafe Enabled - Missing Device or Register results in Relay being De-energized
 Latch De-energize - Requires RTU to Re-energize Relay via Modbus Coil Write

RSD Enabled – For the RSD logic to run, the RSD Enabled check box must be selected. Unselect this box to pause/stop the RSD logic from running.

Failsafe Enabled – If this option is selected **all** rules must have valid data for the relay to be energized. If one or more of the nodes times-out or does not exist the relay will be de-energized.

If this option is not selected, then a node that is not installed or fails to check in will be ignored and the relay will be energized using logic only from the units that are active.

Latch De-Energized – If this option is selected the rules may only de-energize the relay. For the relay to be energized again a Modbus write from a PLC to the gateway for the destination RSD stick relay must occur. This is useful if manual intervention is required before the relay is energized after an event. In the example above, a Modbus coil write to Modbus ID 5 relay channel 1 (which is register 1) is required to energize the relay. See the RSD Stick manual for a detailed register map. If this option is selected, the relay(s) will be forced de-energized when the RSD settings are saved to the gateway, requiring a PLC write to the relay to energize the relay and enter the run state.


The “Normal” state of the relay or digital output is the un-energized state and this state should be used to set the controlled system (pump, motor,...) in the “safe” or “off” state. In the un-energized state the relay COM will be connected to the relay NC terminal. The device should be wired so that when the relay is in this state the system is running. When energized (shut down state) the relay COM will be connected to the NO terminal

15. Local Input/Output


The PATRiOT Gateway v2 has I/O capability built into it locally, with 2 digital inputs, and 2 digital outputs. The state of these inputs and outputs can be viewed by clicking on the **I/O tab in the ToolKit**.

15.1 Digital Inputs


The Gateway has 2 digital inputs, sharing a GND terminal. Digital outputs may be connected to the Gateway as shown in the following diagrams:



Dry Contact Connection



Open Collector Connection




Voltage Pulse Connection

15.2 Digital Outputs

The PATRiOT Gateway has two local open collector. These can be controlled either like any other digital output using the RSD logic table seen above, by writing to registers on the Gateway.

The open collector output can control a relay when wired as shown below.




Note: The digital outputs on the gateway have built in protection and can drive relays and inductive loads directly.

16. Modbus Register Remapping

The PATRIoT gateway allows any of the remote register data to be remapped to a single block of registers available at the Gateway's Modbus ID (default is 247). This is useful for collecting a subset of register data from multiple nodes and making it readable in a single block of registers. Up to 2000 registers can be remapped to the gateway's Modbus ID starting at register 5000.

To configure the remapping, first select **Modbus Register Remapping** from the **Settings** dropdown menu.




Remapped Address	Modbus ID	Address	Register Type	Data Type	Node Name	Register Value	Description
5000	5	2005	Holding Register...	FLOAT	A2HART5	-3.728096	HART1:Primary Varia...
5001	5	2006	Holding Register...	FLOAT			
5002	101	1112	Holding Register...	UINT16	WIOM101	0	DigitalInput1 State
5003	235	3001	Holding Register...	UINT16	Sent235	4936	Sensor A Current (uA)
5004	101	65531	Holding Register...	INT16	WIOM101	-45	RSSI (dBm)
5005	102	65531	Holding Register...	INT16	WIOM102	-44	RSSI (dBm)
5006	101	65532	Holding Register...	UINT16	WIOM101	11972	Supply Voltage (mV)
5007	102	65532	Holding Register...	UINT16	WIOM102	12018	Supply Voltage (mV)
5008			Holding Register...	UINT16		0	
5009			Holding Register...	UINT16		0	
5010			Holding Register...	UINT16		0	
5011			Holding Register...	UINT16		0	
5012			Holding Register...	UINT16		0	
5013			Holding Register...	UINT16		0	
5014			Holding Register...	UINT16		0	

Enter the remote Modbus ID and register address to map to each gateway register and click **Write to GW** to remap the register(s).

The **Data Type**, **Node Name**, **Register Value**, and **Description** fields will automatically be filled in by the gateway once the mapping is written to the gateway.

The ToolKit also supports an Address Picker feature; this will allow you to select from a list of connected nodes or select any SignalFire Node type from the drop down. Then you can simply select the registers you want to add to the remap table by clicking on them and entering the starting address to add them.

In the example below, the user has selected a Wireless-IO Module at Modbus ID 101. Then you can simply select the registers you want to add to the remap table, and enter the address in the table to insert them (5008 in this case), then click apply. These registers will automatically be added to the remap table.



16.1 Use Data Type Floats

The Gateway’s Modbus Register Remapping provides an option to remap all registers to 32-bit floats. This allows the user to enter a register and its data type knowing that it will be read from the gateway via Modbus as two 16-bit registers.


To use the floating-point remapping, select the ‘Remap All Registers Data Type Float’ check box in the lower right of the remap window. This will erase the current register remap in the Gateway; the user will be asked to confirm this action before proceeding.

For each even numbered register address in the remap table, enter the Modbus ID, Register Address, and select the data type. The data types are provided in a pull-down list. Click **Write to GW** to remap the register(s).

The **Node Name**, **Register Value**, and **Description** fields will automatically be filled in by the gateway once the mapping is written to the gateway.

16.2 Fail Mode

If the gateway does not have data for a remapped value it will respond with 0xFFFF, or 0x0000 for the register request, this is configurable globally with the **Fail Mode** settings.



Modbus ID 21 isn't reporting in, fail mode set to "high"

16.3 Import/Export CSV Files

The register map can also be exported or imported from CSV files in a specific format. Exporting the displayed remap information to a CSV file automatically writes the file in the required format. When creating a CSV file to import, use the template generated by clicking the 'CSV Template' button.

If the 'Use Data Type Float' checkbox is checked, the pre-formatted template will include the exact strings required for the data type column for easy 'cut & paste' operations.

17. Modbus Register Map

17.1 PATRIoT Gateway Registers

The SignalFire Modbus Gateway by default is assigned Modbus ID number 247. **Only the Gateway status/configuration and remapped registers are read at this address.** All remote node registers are read from the Modbus ID and register address of the remote node unless Modbus register remapping is used.

Coils

Read coils with Modbus opcode 0x01 (Read Coil). Write coils with Modbus opcode 0x05 (Write Single Coil) or 0x15 (Write Multiple Coils).

Register Address	Register Number	Description	Function Codes	Register Type
Coils (0xxxx)				
0000	00001	Reboot Gateway Coil: Resets the gateway and radio	01, 05, 15	read/write
0001	00002	Reboot Radio Coil: Resets the radio leaving the gateway on	01, 05, 15	read/write
0002	00003	Reset Counter Coil: Resets all counters to zero (See Read Only Registers 2026-2031)	01, 05, 15	read/write
0099	00100	Digital Output 1 Coil	01, 05, 15	read/write
0100	00101	Digital Output 2 Coil	01, 05, 15	read/write

Discrete Inputs

Read discrete inputs with Modbus opcode 0x02 (Read Discrete Inputs).

Register Address	Register Number	Description	Function Codes	Register Type
Discrete Inputs (1xxxx)				
2036	12037	Digital Input 1 State	02	read only
2037	12038	Digital Input 2 State	02	read only

Holding Registers

Read holding registers with Modbus opcode 0x03 (Read Holding Registers) or 0x04 (Read Input Registers). Write holding registers with Modbus opcode 0x06 (Write Single Register) or 0x16 (Write Multiple Registers).

Register Address	Register Number	Description	Function Codes	Register Type
Holding Registers (4xxxx)				
1000	41001	Reboot Gateway: Resets the gateway and radio	03, 04, 06, 16	read/write
1001	41002	Reboot Radio: Resets the radio leaving the gateway on	03, 04, 06, 16	read/write
1002	41003	Reset Counters: Resets all GW status counters to zero (See Read Only Registers 2026-2031)	03, 04, 06, 16	read/write

1119	41120	Digital Output 1 Pulse Time, seconds	03, 04, 06, 16	read/write
1120	41121	Digital Output 2 Pulse Time, seconds	03, 04, 06, 16	read/write
2000	42001	Gateway Radio Node Address	03, 04	read only
2002	42003	Gateway Radio Firmware Major Version	03, 04	read only
2003	42004	Gateway Radio Firmware Minor Version	03, 04	read only
2004	42005	Gateway Firmware Major Version	03, 04	read only
2005	42005	Gateway Firmware Minor Version	03, 04	read only
2006	42007	Gateway Firmware Revision	03, 04	read only
2007	42008	Number of Modbus Servers in Use	03, 04	read only
2008	42009	Number of Modbus Registers in Use	03, 04	read only
2009	42010	SlaveID[15-0]: Bitmask for slave IDs 15-0 (LSB is 0)	03, 04	read only
2010	42011	SlaveID[31-16]: Bitmask for slave IDs 31-16 (LSB is 16)	03, 04	read only
2011	42012	SlaveID[47-32]: Bitmask for slave IDs 47-32 (LSB is 32)	03, 04	read only
2012	42013	SlaveID[63-48]: Bitmask for slave IDs 63-48 (LSB is 48)	03, 04	read only
2013	42014	SlaveID[79-64]: Bitmask for slave IDs 79-64 (LSB is 64)	03, 04	read only
2014	42015	SlaveID[95-80]: Bitmask for slave IDs 95-80 (LSB is 80)	03, 04	read only
2015	42016	SlaveID[111-96]: Bitmask for slave IDs 111-96 (LSB is 96)	03, 04	read only
2016	42017	SlaveID[127-112]: Bitmask for slave IDs 127-112 (LSB is 112)	03, 04	read only
2017	42018	SlaveID[143-128]: Bitmask for slave IDs 143-128 (LSB is 128)	03, 04	read only
2018	42019	SlaveID[159-144]: Bitmask for slave IDs 159-144 (LSB is 144)	03, 04	read only
2019	42020	SlaveID[175-160]: Bitmask for slave IDs 175-160 (LSB is 160)	03, 04	read only
2020	42021	SlaveID[191-176]: Bitmask for slave IDs 191-176 (LSB is 176)	03, 04	read only
2021	42022	SlaveID[207-192]: Bitmask for slave IDs 207-192 (LSB is 192)	03, 04	read only
2022	42023	SlaveID[223-208]: Bitmask for slave IDs 223-208 (LSB is 208)	03, 04	read only
2023	42024	SlaveID[239-224]: Bitmask for slave IDs 239-224 (LSB is 224)	03, 04	read only
2024	42025	SlaveID[255-240]: Bitmask for slave IDs 255-240 (LSB is 240)	03, 04	read only
2025	42026	Supply Voltage: Gateway power supply voltage	03, 04	read only
2026	42027	Radio RX Count: Radio packets received count	03, 04	read only
2027	42028	Radio TX Count: Radio packets sent count	03, 04	read only
2028	42029	RS485RX Count: RS-485 messages received count	03, 04	read only
2029	42030	RS485TX Count: RS-485 messages sent count	03, 04	read only
2030	42031	RS485 Errors: Total Modbus errors from master and slaves	03, 04	read only
2031	42032	Modbus Errors: Modbus exceptions from slave nodes	03, 04	read only
2032	42033	Radio packets received/transmitted per minute. Recommended to be less than 60	03, 04	read only
2033	42034	Radio packets per minute alert. 0 if packets/min <= 60, 1 if packets/min > 60	03, 04	read only
2034	42035	Digital Output 1 State (0=open, 1=closed)	03, 04, 06, 16	read/write
2035	42036	Digital Output 2 State (0=open, 1=closed)	03, 04, 06, 16	read/write
2036	42037	Digital Input 1 State (0=open, 1=closed)	03, 04	read only
2037	42038	Digital Input 2 State (0=open, 1=closed)	03, 04	read only
2038	42039	Unix Epoch Time (seconds since January 1st, 1970)	03, 04	read only
2040	42041	Seconds Since Power On	03, 04	read only
2042	42043	Seconds Since Reboot	03, 04	read only

2100	42101	Address test register. Always returns 2100	03, 04	read only
2101	42102	Address test register. Always returns 2101	03, 04	read only
2102	42103	Address test register. Always returns 2102	03, 04	read only
4001	44002	Status of Modbus ID 1:Returns 1 if Modbus Device is present and 0 if not present	03, 04	read only
4002	44003	Status of Modbus ID 2:Returns 1 if Modbus Device is present and 0 if not present	03, 04	read only
...	03, 04	read only
4240	44241	Status of Modbus ID 240:Returns 1 if Modbus Device is present and 0 if not present	03, 04	read only

17.2 Output Module Registers

When the optional Analog/Relay or 12DO outputs module(s) are attached to the PATRIoT Gateway additional registers are available to control the outputs.

Coils

Read coils with Modbus opcode 0x01 (Read Coil). Write coils with Modbus opcode 0x05 (Write Single Coil) or 0x15 (Write Multiple Coils).

Register Address	Register Number	Description	Function Codes	Register Type
Coils (0xxxx)				
0101	00102	Analog/Relay Module 1 Relay 1 Coil	01, 05, 15	read/write
0102	00103	Analog/Relay Module 1 Relay 2 Coil	01, 05, 15	read/write
0103	00104	Analog/Relay Module 2 Relay 1 Coil	01, 05, 15	read/write
0104	00105	Analog/Relay Module 2 Relay 2 Coil	01, 05, 15	read/write
0131	00132	Digital Output Module 1 Output 1 Coil	01, 05, 15	read/write
0132	00133	Digital Output Module 1 Output 2 Coil	01, 05, 15	read/write
0133	00134	Digital Output Module 1 Output 3 Coil	01, 05, 15	read/write
0134	00135	Digital Output Module 1 Output 4 Coil	01, 05, 15	read/write
0135	00136	Digital Output Module 1 Output 5 Coil	01, 05, 15	read/write
0136	00137	Digital Output Module 1 Output 6 Coil	01, 05, 15	read/write
0137	00138	Digital Output Module 1 Output 7 Coil	01, 05, 15	read/write
0138	00139	Digital Output Module 1 Output 8 Coil	01, 05, 15	read/write
0139	00140	Digital Output Module 1 Output 9 Coil	01, 05, 15	read/write
0140	00141	Digital Output Module 1 Output 10 Coil	01, 05, 15	read/write
0141	00142	Digital Output Module 1 Output 11 Coil	01, 05, 15	read/write
0142	00143	Digital Output Module 1 Output 12 Coil	01, 05, 15	read/write
0143	00144	Digital Output Module 2 Output 1 Coil	01, 05, 15	read/write
0144	00145	Digital Output Module 2 Output 2 Coil	01, 05, 15	read/write

0145	00146	Digital Output Module 2 Output 3 Coil	01, 05, 15	read/write
0146	00147	Digital Output Module 2 Output 4 Coil	01, 05, 15	read/write
0147	00148	Digital Output Module 2 Output 5 Coil	01, 05, 15	read/write
0148	00149	Digital Output Module 2 Output 6 Coil	01, 05, 15	read/write
0149	00150	Digital Output Module 2 Output 7 Coil	01, 05, 15	read/write
0150	00151	Digital Output Module 2 Output 8 Coil	01, 05, 15	read/write
0151	00152	Digital Output Module 2 Output 9 Coil	01, 05, 15	read/write
0152	00153	Digital Output Module 2 Output 10 Coil	01, 05, 15	read/write
0153	00154	Digital Output Module 2 Output 11 Coil	01, 05, 15	read/write
0154	00155	Digital Output Module 2 Output 12 Coil	01, 05, 15	read/write

Holding Registers

Read holding registers with Modbus opcode 0x03 (Read Holding Registers) or 0x04 (Read Input Registers).

Write holding registers with Modbus opcode 0x06 (Write Single Register) or 0x16 (Write Multiple Registers).

Register Address	Register Number	Description	Function Codes	Register Type
Holding Registers (4xxxx)				
1101	41102	Analog/Relay Module 1 Relay 1 State	03, 04, 06, 16	read/write
1102	41103	Analog/Relay Module 1 Relay 2 State	03, 04, 06, 16	read/write
1103	41104	Analog/Relay Module 2 Relay 1 State	03, 04, 06, 16	read/write
1104	41105	Analog/Relay Module 2 Relay 2 State	03, 04, 06, 16	read/write
1121	41122	Analog/Relay Module 1 Relay 1 Pulse Time, seconds	03, 04, 06, 16	read/write
1122	41123	Analog/Relay Module 1 Relay 2 Pulse Time, seconds	03, 04, 06, 16	read/write
1123	41124	Analog/Relay Module 2 Relay 1 Pulse Time, seconds	03, 04, 06, 16	read/write
1124	41125	Analog/Relay Module 2 Relay 2 Pulse Time, seconds	03, 04, 06, 16	read/write
1131	41132	Digital Output Module 1 Output 1 State	03, 04, 06, 16	read/write
1132	41133	Digital Output Module 1 Output 2 State	03, 04, 06, 16	read/write
1133	41134	Digital Output Module 1 Output 3 State	03, 04, 06, 16	read/write
1134	41135	Digital Output Module 1 Output 4 State	03, 04, 06, 16	read/write
1135	41136	Digital Output Module 1 Output 5 State	03, 04, 06, 16	read/write
1136	41137	Digital Output Module 1 Output 6 State	03, 04, 06, 16	read/write
1137	41138	Digital Output Module 1 Output 7 State	03, 04, 06, 16	read/write
1138	41139	Digital Output Module 1 Output 8 State	03, 04, 06, 16	read/write
1139	41140	Digital Output Module 1 Output 9 State	03, 04, 06, 16	read/write
1140	41141	Digital Output Module 1 Output 10 State	03, 04, 06, 16	read/write
1141	41142	Digital Output Module 1 Output 11 State	03, 04, 06, 16	read/write
1142	41143	Digital Output Module 1 Output 12 State	03, 04, 06, 16	read/write
1143	41144	Digital Output Module 2 Output 1 State	03, 04, 06, 16	read/write
1144	41145	Digital Output Module 2 Output 2 State	03, 04, 06, 16	read/write
1145	41146	Digital Output Module 2 Output 3 State	03, 04, 06, 16	read/write
1146	41147	Digital Output Module 2 Output 4 State	03, 04, 06, 16	read/write
1147	41148	Digital Output Module 2 Output 5 State	03, 04, 06, 16	read/write

1148	41149	Digital Output Module 2 Output 6 State	03, 04, 06, 16	read/write
1149	41150	Digital Output Module 2 Output 7 State	03, 04, 06, 16	read/write
1150	41151	Digital Output Module 2 Output 8 State	03, 04, 06, 16	read/write
1151	41152	Digital Output Module 2 Output 9 State	03, 04, 06, 16	read/write
1152	41153	Digital Output Module 2 Output 10 State	03, 04, 06, 16	read/write
1153	41154	Digital Output Module 2 Output 11 State	03, 04, 06, 16	read/write
1154	41155	Digital Output Module 2 Output 12 State	03, 04, 06, 16	read/write
2044	42045	Analog/Relay Module 1 Analog Output 1, microamps (μ A)	03, 04, 06, 16	read/write
2045	42046	Analog/Relay Module 1 Analog Output 2, microamps (μ A)	03, 04, 06, 16	read/write
2046	42047	Analog/Relay Module 1 Analog Output 3, microamps (μ A)	03, 04, 06, 16	read/write
2047	42048	Analog/Relay Module 1 Analog Output 4, microamps (μ A)	03, 04, 06, 16	read/write
2048	42049	Analog/Relay Module 1 Analog Output 5, microamps (μ A)	03, 04, 06, 16	read/write
2049	42050	Analog/Relay Module 1 Analog Output 6, microamps (μ A)	03, 04, 06, 16	read/write
2050	42051	Analog/Relay Module 1 Analog Output 7, microamps (μ A)	03, 04, 06, 16	read/write
2051	42052	Analog/Relay Module 1 Analog Output 8, microamps (μ A)	03, 04, 06, 16	read/write
2052	42053	Analog/Relay Module 2 Analog Output 1, microamps (μ A)	03, 04, 06, 16	read/write
2053	42054	Analog/Relay Module 2 Analog Output 2, microamps (μ A)	03, 04, 06, 16	read/write
2054	42055	Analog/Relay Module 2 Analog Output 3, microamps (μ A)	03, 04, 06, 16	read/write
2055	42056	Analog/Relay Module 2 Analog Output 4, microamps (μ A)	03, 04, 06, 16	read/write
2056	42057	Analog/Relay Module 2 Analog Output 5, microamps (μ A)	03, 04, 06, 16	read/write
2057	42058	Analog/Relay Module 2 Analog Output 6, microamps (μ A)	03, 04, 06, 16	read/write
2058	42059	Analog/Relay Module 2 Analog Output 7, microamps (μ A)	03, 04, 06, 16	read/write
2059	42060	Analog/Relay Module 2 Analog Output 8, microamps (μ A)	03, 04, 06, 16	read/write
2060	42061	Analog/Relay Module 1 Analog Output 1, millivolts (mV)	03, 04, 06, 16	read/write
2061	42062	Analog/Relay Module 1 Analog Output 2, millivolts (mV)	03, 04, 06, 16	read/write
2062	42063	Analog/Relay Module 1 Analog Output 3, millivolts (mV)	03, 04, 06, 16	read/write
2063	42064	Analog/Relay Module 1 Analog Output 4, millivolts (mV)	03, 04, 06, 16	read/write
2064	42065	Analog/Relay Module 1 Analog Output 5, millivolts (mV)	03, 04, 06, 16	read/write
2065	42066	Analog/Relay Module 1 Analog Output 6, millivolts (mV)	03, 04, 06, 16	read/write
2066	42067	Analog/Relay Module 1 Analog Output 7, millivolts (mV)	03, 04, 06, 16	read/write
2067	42068	Analog/Relay Module 1 Analog Output 8, millivolts (mV)	03, 04, 06, 16	read/write
2068	42069	Analog/Relay Module 2 Analog Output 1, millivolts (mV)	03, 04, 06, 16	read/write
2069	42070	Analog/Relay Module 2 Analog Output 2, millivolts (mV)	03, 04, 06, 16	read/write
2070	42071	Analog/Relay Module 2 Analog Output 3, millivolts (mV)	03, 04, 06, 16	read/write
2071	42072	Analog/Relay Module 2 Analog Output 4, millivolts (mV)	03, 04, 06, 16	read/write
2072	42073	Analog/Relay Module 2 Analog Output 5, millivolts (mV)	03, 04, 06, 16	read/write
2073	42074	Analog/Relay Module 2 Analog Output 6, millivolts (mV)	03, 04, 06, 16	read/write
2074	42075	Analog/Relay Module 2 Analog Output 7, millivolts (mV)	03, 04, 06, 16	read/write
2075	42076	Analog/Relay Module 2 Analog Output 8, millivolts (mV)	03, 04, 06, 16	read/write

18. Disposal Instructions

To ensure environmental safety and compliance, please follow these disposal instructions for the product and its components:

Electronic Components:

This product contains electronics must be recycled through approved e-waste recycling programs. Electronics can contain harmful materials and should be prevented from entering landfills. Do not place electronics in regular trash.

Metal Parts:

Any metal components can be separated and recycled through your local metal recycling facility.

Packaging Materials:

Recycle or reuse packaging materials such as cardboard or plastics, following local recycling guidelines.

For local disposal sites refer to:

- [Call2Recycle](#) (USA, Canada)
- [Earth911](#) (USA, Canada)
- [SERI](#) (International)

In the USA or more information, visit:

- [EPA's battery disposal guide](#)
- [EPA's electronics recycling page](#)

By following these guidelines, you help reduce waste and support environmental sustainability.

19. FCC and IC Statements

This device contains FCC ID: W8V-SFTS500, IC: 8373A-SFTS500. Changes or modifications not expressly approved by SignalFire Telemetry, Inc could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been designed to operate with the antennas listed below, and having a maximum gain of 5.8 dBi. Antennas not included in this list or having a gain greater than 5.8 dBi are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

To comply with FCC's and IC's RF radiation exposure requirements, the antenna(s) used for this transmitter must be installed such that a minimum separation distance of 20cm is maintained between the radiator (antenna) & user's/nearby person's body at all times and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Revision	Date	Changes/Updates
1.0	10/13/25	Initial release
1.1	11/26/25	Added Modbus-RTU Client and output module support
1.2	2/10/26	Added EtherNet/IP Support
1.3	2/18/26	Added C1D2 Certification Details

Technical Support And Contact Information

SignalFire Telemetry
140 Locke Dr., Suite B
Marlborough, MA 01749

(978) 212-2868
support@signal-fire.com

