


# SignalFire A2-HART

## External Sensor Loop Power Wiring Diagram

1 to 4 HART Sensors Configured for HART ID's 1 through 4



**Configure sensor on time to 0 seconds**

### SignalFire Telemetry

Part Name	A2-HART External Loop Power	Date	12/16/13
Part Number	960-0051-01	Rev	A
Material			