

# Ranger-900 Manual



The Ranger-900 is an integrated assembly that allows a local 900MHz radio network to communicate with the SignalFire Cloud over an LTE-M1 cellular network.

- DIN Gateway v2 and Ranger-Modbus integrated into a single enclosure
- Solar panel, rechargeable battery, and power management system included
- Configurable from the SignalFire Cloud website signal-fire.cloud
- SignalFire Cloud allows for data visualization, trending and alarming
- Supports MQTT Sparkplug B communication protocol for connection to other servers
- Compact and simple to install and maintain
- Local configuration and diagnostics available using the SignalFire ToolKit and SignalFire Ranger ToolKit
- Internal backlog of a minimum of 200 datapoints in the event of loss of signal. Backlog will be automatically sent when the Ranger reconnects

# Specifications

Specifications					7			
Enclosure	UL/NEMA 4X (IP66/68) rated Polycarbonate. 14.1" tall × 9.8" wide × 7.0" deep							
Power Source	10W solar panel, 12A-hr rechargeable SLA battery backup, 4.5A battery management system. Or optional 10-30VDC input							
Temperature Rating	-40°C to +85°C							
SIM Slot	Nano SIM card	(LTE C	Cat M S	SIM and data plan required)				
Local config port	Micro-USB (RAN	IGER)	, DB-9	9 (Gateway)				
Analog Input	1 active (13/18V selectable power out) analog input, 4-20mA/1-5V. 3 passive analog inputs, 1-5V or 4-20mA with precision $250\Omega$ resistor							
Digital Inputs	4 digital inputs. Dry Contact or 30 Volts Max (push-pull), 2kHz max							
Relay Output	Latching Relay. 2A @ 30VDC, 0.3A @ 110VDC, 0.5A @ 125VAC							
Sensor Power Output	Selectable 13V/18V. 60mA max power output							
Compliance	<ul><li>Contains</li><li>Verizon,</li></ul>	s FCC AT&1	ID: 2A <sup>-</sup> Netw	NPO00NRF9160 and IC ID: 24529-NRF9160 ork Certified				
Model Numbers	RANGER-900			RANGER LTE M1 Transmitter - Enclosure with 900MHz network radio integrated with DIN Ranger				
Model Mullipers	-Solar			Integrated 12V battery with charger and solar panel	_			
	-DC			10-30VDC input. User provides DC power	-			
	-Mode	ous		RS485 Modbus Serial port				
		-NoSIM		No SIM Card. No SignalFire Cloud. User provides LTE CAT M1 SIM Card				
		-VZSIM1		VERIZON LTE CAT M1 SIM - 1 Year Data Plan, SignalFire Cloud Connectivity	_			
		-VZSIM3	41	VERIZON LTE CAT M1 SIM - 3 Year Data Plan, SignalFire Cloud Connectivity	_			
		-SFCloud	13	No SIM Card, 3 year Signal Fire Cloud, User provides LTE CAT MI SIM Card	-			
		-1	1	N/A				
		- N	/IB32	Up to 32 MODBUS registers				
		- N	/B96	Up to 96 MODBUS registers - 1 Year Plan	_			
			-N	N/A 60 coconde minimum	_			
			-SID	ou seconds minimum 15 seconds minimum - 1 Year Plan	-			
			-Ultra	5 seconds minimum - 1 Year Plan	_			
			-	N/A				

# Mechanical Dimensions







# Table of Contents

Specifications	2
Mechanical Dimensions	3
Table of Contents	4
Hazardous Location Certification	5
Overview	5
Power	5
Software Configuration	5
Sensor Connections	5
Setup	6
Power	6
Cloud	7
Gateway	7
RANGER	8
Cloud Setup and Information	. 10
Technical Support and Contact Information	.11
Revision History	.11

# Hazardous Location Certification

The RANGER-900 is not Hazardous Location certified and is for general purpose areas only.

### Overview

The RANGER-900 provides a convenient way to bring data from SignalFire's 900MHz nodes into the SFCloud, creating a hybrid system of radio and cellular technology, local and remote. The RANGER-900 is a standalone enclosure that consists of a DIN Gateway v2 and RANGER-DIN mount, powered by an integrated solar system or DC input.

The system supports our line of 900MHz nodes such as the C1D1 Sentinel or Pressure Scout, which connect to the DIN Gateway v2. While normally this information would then be read from the Gateway over Modbus into a PLC/SCADA system, the RANGER-900 can transmit this information to the SignalFire Cloud. With this flexibility, users don't have to split their data between local systems and the SignalFire Cloud where they see other RANGER data.

#### Power

The RANGER-900 is powered by a 10W solar panel, with a rechargeable 12A-hr SLA backup battery. A fully charged battery can provide power for over 16 days. An optional DC input is also available for situations were local power exists.

### Software Configuration

The RANGER can be configured locally through its micro-USB port using the SignalFire RANGER ToolKit. The DIN Gateway v2 can be configured locally through its DB-9 port using the SignalFire ToolKit. Both pieces of software can be downloaded from our website, <u>signal-fire.com</u>, with registration of a free account.

### Sensor Connections

The RANGER-DIN and DIN Gateway v2 both support a variety of integrated I/O. Wires can be brought in through the cable glands on the enclosure's underside. For more information on their I/O capabilities, please refer to their respective manuals.

Using the RANGER's active analog input will impact battery life and is generally not recommended for use when on solar power unless the sensor power requirements are low. Contact SignalFire or your local vendor for applications where the RANGER's analog input will need to be used.

# Setup

### Power

The solar panel and battery will be packed separately and need to be assembled with the enclosure. Please follow the step-by-step instructions below to get power to the system.

- 1. Unlock the enclosure and open the door.
- 2. Pull the solar panel's wire in through the cable gland on the underside of the enclosure and land them on the terminals as shown below, such that red goes to red and black goes to black.



- 3. Tighten the cable gland until the solar panel cable is secure.
- 4. Install the battery by inserting it into the enclosure on the strap as shown below. Pull the Velcro strap through the buckle and secure tightly.



5. Insert the disconnects on to the battery's tabs, red to red, black to black. The system will then be fully powered on.



# Cloud

RANGER-900's purchased with the SignalFire Cloud service come with a pre-installed SIM card. Customers will require a login to access the SignalFire Cloud server (<u>signal-fire.cloud</u>). Fill out the request form here: <u>https://signal-fire.com/lte-m1-cellular-products/cloudregister/</u> to setup your company site. Once your account is created, follow the steps below:

- 1. Login to the SignalFire Could with the account login/password provided
- 2. From the Home page click "Add Device"
- 3. Enter either the RANGER serial number or IMEI number and click "Send Request". The serial number and IMEI number are located on inside of the enclosure door. The serial number will have a format of "RA" followed by 6 numbers.
- 4. A message will be sent to the RANGER to "claim" it to the customer site, and a wait screen with appear.
- 5. Within approximately one minute the device will connect to your account and you will be automatically redirected to the device status page

#### Gateway

The Gateway and its nodes should be configured as normal. Connect to the Gateway through the DB-9 port with the SignalFire ToolKit and set the Network, Network Group, and Encryption Key parameters as needed. To add a node to its network, simply configure it to have the same Network, Network Group, and Encryption Key along with a unique Slave ID. For more information, please refer to the DIN Gateway v2 manual.

### RANGER

The RANGER can be programmed to pull individual registers from the Gateway from the various nodes. To do so, click on the "Configure" button on the Modbus tile.

Mode	US			CONFIGURE
Passing / Total	Reads:			
				32
Polled Devices:		Enabled Al	arms:	
Baud Rate	9600	Mode	8N1	
	Request Delay	0		
Re	sponse Timeout	1000		

The RANGER can read up to 32 datapoints (or 96 with an expanded subscription) from up to 8 connected devices. To add a new register read, click on the '+' button. Each line needs to be specified with a Tag Name, and point to a Modbus Slave ID, register address, register data type, and read/write access. The register can also be tagged with units if needed. Click Apply to send the changes to the RANGER.

To select lines for deletion, click on the trash can icon at the end of each line, and then click on the "Delete Rows" button to delete all the rows selected.

Once the registers have been set up as desired, click "Exit" to return to the RANGER's main page. The registers and their values will appear in a table below, where they can be organized in ascending or descending order by clicking on each header. The Modbus register configuration can also be done locally using the RANGER ToolKit.

Because the RANGER's Modbus capability is limited to reading 32 (or 96) registers from 8 devices, SignalFire recommends using register remapping on the Gateway. That way, all registers can be read from a single device (the Gateway's Modbus ID).

MODBUS SETTINGS							APPLY	EXIT		
Curre	Current Settings on Node									
	Baud	9600	~	Serial Mode	8N1 (8 Data Bits,	No 🗸	Byte Order	ABCD (High	word, Hi	~
		Request Delay 0			Respons	e Timeout 1,00	D			
► R	REGISTERS: 6 DELETE ROWS APPLY									
		Tag Name	ID	Address	Ту	rpe	Unit		Access	+
0.	3000 Volta	age	1	3000	HOLDI 🗸	UINT16 🗸	mV	Read	/w 🗸	Î
1.	3001 PSI i	nt	1	3001	HOLDI 🗸	UINT16 🗸		Read	/w 🗸	Î
2.	3006 Spar	1	1	3006	HOLDI 🗸	UINT16 🗸		Read	/w 🗸	Î
3.	3008 PSI f	loat	1	3008	HOLDI 🗸	FLOAT 🗸	PSI	Read	/w 🗸	Î
4.	3010 Scale	ed	1	3010	HOLDI 🗸	FLOAT 🗸		Read	/w 🗸	Î
5.	Solar Batt	ery	247	2025	HOLDI 🗸	UINT16 🗸	mV	Read	/w 🗸	Î

In the example above, the RANGER is transmitting information from a Pressure Scout as well as the Gateway's supply voltage.

Clicking on "Show In Trend" will add that register to the historical data view at the bottom of the page. Clicking on "Modify" will bring a pop-up to configure alarms, or to do a register write to set a Modbus value in a register. Every register can be individually set up with Low and High alarm thresholds. Click "Apply" to save alarm settings for each register.

FLOAT	1	APPLY					
Current Settings on Node							
Register Value	700.553100						
> ALARN	APPLY						
Current Settings on Cloud							
Low Alarm Threshold	0	Disabled 🗸					
High Alarm Threshold	0	Disabled 🗸					

For additional details on the RANGER and the SignalFire Cloud, please reference the RANGER-DIN product manual

# Cloud Setup and Information

Full documentation on using the SignalFire Cloud features and how to remotely configure your RANGER is available in an online knowledge base. The manual provides instructions on user management, configuring alarms, generating reports, and more. Whether you are a new or experienced user, this manual serves as a valuable resource to maximize the platform's capabilities.

https://www.signal-fire.com/cloud-manual/



Link to SF Cloud Account Creation

Devices purchased with the SignalFire Cloud service come with a pre-installed SIM card. Customers will require a login to access the SignalFire Cloud server. Please fill out the request form using the button on the right below to set up your company site.

# Adding the RANGER to your SignalFire Cloud Group

- 1. Plug in the battery so the RANGER can connect to the cellular network.
- 2. Verify that the RANGER is connected to the cellular network by pressing the "CHECKIN" button on the device and observe 3 strobes of the green status light.
- 3. Login to the SignalFire Cloud with your account login/password
- 4. From the Home page click "Add Device"
- 5. Enter the RANGER serial number and click "Claim". The serial number is located on the bottom of the RANGER with a format of "RA" followed by 6 numbers. (e.g. RA123456)
- 6. A message will be sent to the RANGER to claim it to your group account
- 7. Within approximately one minute the device will connect to your account, and you will be automatically redirected to the device status page

# Technical Support and Contact Information

11

SignalFire Telemetry 140 Locke Dr, Suite B Marlborough, MA 01749 (978) 212-2868 support@signal-fire.com

# **Revision History**

Revision	Date	Changes/Updates
1.0	05/14/21	Initial release
1.1	08/02/23	Updated to reference RANGER-DIN and added DC power option